

REX zero 1 CP



SCALE 2.000

Pos.:	Item Description:	Code:	Number of Pieces:
1	Front Sight	402 005	1
2	Rear Sight	402 006	1
3	Loaded Chamber Indicator	402 007	1
4	Loaded Chamber Indicator Axel	402 008	1
5	Lock Chamber Indicator Spring	402 009	1
6	Firing Pin	501 791	1
7	Firing Pin Spring	402 010	1
8	Firing Pin Block Spring	402 011	1
9	Firing Pin Block Plunger	501 803	1
10	Firing Pin Extractor Locking Pin	402 013	1
11	Extractor	501 810	1
12	Slide CP	501 718	1
13	Barrel CP	500 058	1
14	Recoil Spring Guide CP	501 799	1
15	Recoil Spring CP	402 107	1
16	Unlocking Block	501 790	1
17	Slide Stop Spring	402 017	1
18	Disassembly Lever	501 801	1
19	Trigger Bar Pin	501 684	1
20	Trigger Bar	501 814	1
21	Sear Axle	501 398	1
22	Spring Limiting Pin	402 021	1
23	Sear	501 805	1
24	Sear Spring	402 023	1
25	Firing Pin Block Lever	501 817	1
26	Ejector	501 820	1
27	Rest	402 026	1
28	Rest Axle	501 392	1
29	Hammer	402 028	1
30	Hammer Axle	501 794	1
31	Rest Spring Axle	501 394	1
32	Rest Spring	402 031	1
33	Trigger Bar Spring	402 032	1
34	Right Hand Safety Lever	402 033	1
35	Left Hand Safety Lever	402 034	1
36	Safety Lever Pin	402 035	1
37	Safety Lever Indexing Plunger	501 793	1
38	Safety Lever Spring	402 036	1
39	Hammer Spring	402 037	1
40	Hammer Strut	501 823	1
42	Trigger	402 040	1
43	Slide Stop	501 826	1
44	Trigger Axle	501 796	1
45	Slide Catch Decocker Lever	402 043	1
46	Slide Catch Decocker Lever Holder	402 044	1
47	Slide Catch Decocker Lever Holder Spring	402 045	1
48	Magazine Catch	402 046	1
49	Magazine Catch Axle	501 405	1
50	Magazine Catch Spring	402 048	1
51	Magazine Release Button	402 049	1
52	Left Grip Panel	501 895	1
53	Grip panel Screw	501 830	4
54	Right Grip Panel	501 895	1
55	Slide Catch Decocker Lever Spring	402 050	1
56	Frame CP	502 075	1